

# **User Manual**

## **DA16200 AT GUI Tool**

### **UM-WI-004**

---

## Contents

<b>Contents</b> .....	<b>2</b>
<b>Figures</b> .....	<b>3</b>
<b>Terms and Definitions</b> .....	<b>4</b>
<b>References</b> .....	<b>4</b>
<b>1 Introduction</b> .....	<b>5</b>
1.1 Certification Mode .....	5
1.2 Network Mode .....	5
1.3 OTP Mode.....	5
<b>2 How to Connect</b> .....	<b>5</b>
2.1 USB to Serial Driver .....	5
2.2 Setup Serial Terminal Utility.....	6
<b>3 How to Run GUI for DA16200 Board</b> .....	<b>7</b>
3.1 Board Setup .....	7
3.2 Board Connection .....	9
3.3 RF Certification Mode .....	10
3.4 TX Test Mode.....	10
3.5 RX Test Mode .....	13
<b>4 Network Mode</b> .....	<b>14</b>
4.1 Station Mode .....	15
4.2 AP Mode .....	17
4.3 Data Transfer (TCP/UDP).....	19
4.3.1 TCP Server .....	19
4.3.2 TCP Client .....	20
4.3.3 UDP Session .....	21
4.3.4 Data Exchange .....	21
4.3.5 Data Transfer on DPM Mode.....	22
4.4 MQTT Client.....	24
4.4.1 Configuration .....	24
4.4.2 Data Exchange .....	25
4.4.3 MQTT on DPM Mode.....	25
4.5 TLS Setting .....	26
<b>5 OTP Mode Setup</b> .....	<b>27</b>
<b>6 How to Build GUI for DA16200 Board</b> .....	<b>28</b>
<b>Revision History</b> .....	<b>31</b>

## DA16200 AT GUI Tool

## Figures

Figure 1: Terminal Configuration.....	6
Figure 2: Development Kit Connections.....	7
Figure 3: AT GUI .....	8
Figure 4: RS232 Setup - Disconnected.....	9
Figure 5: RS232 Setup - Connected .....	9
Figure 6: Debug Console - Connected.....	9
Figure 7: Certification Mode Configuration.....	10
Figure 8: Certification Mode Tab.....	10
Figure 9: Tx Test Mode Configuration.....	10
Figure 10: Debug Console - TX Mode.....	11
Figure 11: Start and Stop TX.....	11
Figure 12: Debug Console - Start TX .....	12
Figure 13: Debug Console - Stop TX .....	12
Figure 14: Rx Configuration.....	13
Figure 15: Network Mode Configuration.....	14
Figure 16: Network Mode Tab.....	14
Figure 17: Setup Window - Station Mode.....	15
Figure 18: Station Mode - SCAN.....	15
Figure 19: Station Mode - Choose AP and Connect .....	16
Figure 20: Debug Console - Connect to AP .....	16
Figure 21: Setup Window - AP Mode .....	17
Figure 22: AP Configuration .....	18
Figure 23: Debug Console - AP Configuration .....	18
Figure 24: DHCP Configuration.....	18
Figure 25: Debug Console - DHCP Configuration .....	18
Figure 26: Data Transfer Tab .....	19
Figure 27: TCP Server Open.....	19
Figure 28: TCP Server Connection with a Client.....	20
Figure 29: TCP Client Connection to a Server .....	20
Figure 30: UDP Session Open .....	21
Figure 31: TCP Server Data Transfer .....	21
Figure 32: TCP Client Data Transfer.....	22
Figure 33: UDP Session Data Transfer.....	22
Figure 34: TCP/UDP Data Reception.....	22
Figure 35: DPM Mode Setting .....	22
Figure 36: MQTT Client Tab.....	24
Figure 37: MQTT PUBLISH Transfer .....	25
Figure 38: MQTT PUBLISH Reception .....	25
Figure 39: TLS Setting Tab .....	26
Figure 40: OTP Mode.....	27
Figure 41: GUI Source Codes Structure .....	28
Figure 42: Dialog GUI Project.....	28
Figure 43: Local Windows Debugger Execution .....	29
Figure 44: GUI Files .....	29
Figure 45: Solution Explorer Tab.....	29
Figure 46: Resource View Tab.....	30

---

## DA16200 AT GUI Tool

### Terms and Definitions

GUI	Graphical User Interface
UART	Universal Asynchronous Receiver Transmitter
SSID	Service Set Identifier
DHCP	Dynamic Host Configuration Protocol
AP	Access Point
USB	Universal Serial Bus
MFC	Microsoft Foundation Class

### References

- [1] DA16200, Datasheet, Dialog Semiconductor
- [2] DA16200, SDK Programmer Guide, User Manual, Dialog Semiconductor
- [3] DA16200, EVK User Guide, Dialog Semiconductor
- [4] DA16200, AT Command User Guide, Dialog Semiconductor

## DA16200 AT GUI Tool

### 1 Introduction

The DA16200 GUI tool (Dialog\_IoTWiFi\_GUI\_YYYYMMDD.EXE) lets users control the DA16200 EVK in a GUI environment. There are two modes of operation: Certification mode and Network mode.

#### 1.1 Certification Mode

This mode is for Wi-Fi RF test (Tx power, Rx sensitivity, etc.) also known as “TEST Mode”.

#### 1.2 Network Mode

With Network mode, the Station or AP mode of the DA16200 is tested.

- **AP mode:** Soft-AP test with configurable parameters like SSID, security, DHCP Server, etc
- **Station mode:** STA test to search and connect to an Access Point and check/test the STA function

After the network mode is set, the user can test the TCP/UDP or the MQTT protocol and manage the TLS certificates.

- **Data Transfer:** message exchange through the TCP Server/Client, and UDP session
- **MQTT Client:** message exchange through the MQTT protocol
- **TLS Setting:** management of TLS certificate that is set (e.g. Root CA, Client Certificate, Client Private Key)

#### 1.3 OTP Mode

This mode is for **power calibration** and **temperature calibration with OTP memory location**.

### 2 How to Connect

#### 2.1 USB to Serial Driver

The DA16200 evaluation board supports both serial port (UART) and USB port (default USB). The user connects with a micro-USB cable and then two COM ports will be detected automatically.

- If USB port is used, install the FT232 Driver for windows
- In most cases, it will be installed automatically

The FTDI driver for the FT2232 FTDI chip used on the Pro-DK motherboard is available for download at the following link: [http://www.ftdichip.com/Drivers/CDM/CDM21224\\_Setup.zip](http://www.ftdichip.com/Drivers/CDM/CDM21224_Setup.zip)

When the PC and the EVB board are connect, two ports will be detected.

- See the EVK User Guide [3] to find information about the UART1 port. GUI tool uses UART1 port.  
The other port (UART0) is for debug console connection. This port is used for firmware updates.
- To update with a new DA16200 firmware, see the DA16200 EVK User Guide [3].

The RF certification program was developed by MFC. Therefore, this program may require installation of the MFC library package.

- The Visual Studio Redistributable file is available for download at:  
<https://www.microsoft.com/en-us/download/details.aspx?id=48145>
- Select the Windows OS type (32-bit or 64-bit), and then do download and install.

DA16200 AT GUI Tool

2.2 Setup Serial Terminal Utility

Users can control DA16200 with a serial terminal tool (such as Teraterm or SecureCRT). The following configurations are required to connect to the console of DA16200:

- Port: Com port number on Windows system
- Baud rate: 115,200 bps
- Data bits: 8 bits
- Parity: None
- Stop bits: 1 bit
- Flow control: None




Figure 1: Terminal Configuration

When the DA16200 board is connected, the Windows operating system will detect two COM ports. One (UART0) is for console command and the other (UART1) is for AT command. Normally, the higher number COM port is for AT commands and the lower number COM port is for the console.

## DA16200 AT GUI Tool

### 3 How to Run GUI for DA16200 Board

#### 3.1 Board Setup

Some source files need to be modified in the DA16200 SDK to use the GUI function.

Enable AT Command function as shown in the example below.

```
[\\src\\customer\\config_generic_sdk.h]

// AT-CMD features
#define __SUPPORT_ATCMD__           // Support AT-CMD

[\\src\\customer\\sys_common_features.h]

#define __SUPPORT_NET_CMD__         // Network feature commands
#define __SUPPORT_LMAC_RF_CMD__    // lmac/rf feature commands
#define __SUPPORT_PERI_CMD__       // peri. feature commands
```


DA16200 AT GUI program is a single executable file.

#### NOTE

If there is an error with the message "a DLL file (e.g. *vcruntime140.dll* or *mfc1400u.dll*) is missing", then install Microsoft Visual Studio redistributable package (<https://www.microsoft.com/en-us/download/details.aspx?id=48145>) or copy the .dll file into the Windows system folder (C:\\Windows\\System32 or C:\\Windows\\SysWOW64).

The program setup sequence is:

1. Connect the DA16200 Development Kit to the host PC as shown in [Figure 2](#).



**Figure 2: Development Kit Connections**

#### NOTE

See the EVK User Guide [\[3\]](#) to know which port to use.

## DA16200 AT GUI Tool

2. Start the AT GUI program.




Figure 3: AT GUI



DA16200 AT GUI Tool

3.2 Board Connection

1. When the AT GUI program runs, the connection status is red (not connected). If the program does not detect any COM port, click the **R** button to refresh the COM Port. See [Figure 4](#).




Figure 4: RS232 Setup - Disconnected

2. Select a COM port and click the RS232 **OPEN** button and wait for a few seconds. See [Figure 5](#) and [Figure 6](#).
  - o The connection status will soon change to a green color and the Connection Status field shows "Connected" in a green color. This means that communication is OK.




Figure 5: RS232 Setup - Connected

- o In the Debug Console window (in the black box), the message "Echo on" is shown.




Figure 6: Debug Console - Connected

DA16200 AT GUI Tool

3.3 RF Certification Mode

To enable certification mode:

1. Open the **Chip Setting** tab. See [Figure 7](#).
2. In the **RF Mode** area, select the **Certification Mode** check box.




Figure 7: Certification Mode Configuration

- Alternatively, on the **Certification Mode** tab, select the **Certification Mode** checkbox. See [Figure 8](#).




Figure 8: Certification Mode Tab

3.4 TX Test Mode

1. Open the **Certification Mode** tab. See [Figure 9](#).




Figure 9: Tx Test Mode Configuration

2. Click the **Mode Select** button ([Figure 9](#)). A confirmation message is shown as in [Figure 10](#). This is a normal state.

DA16200 AT GUI Tool

```

AT+TMRFRNOINIT=1
OK
AT+RESTART
OK
+INIT:DONE

Echo on
OK
AT+RFTESTSTART
OK
    
```

Figure 10: Debug Console - TX Mode

3. Select the **Data Rate**, **Channel**, and **Power** for the purpose of the test.
  - **Packet mode**: this is the normal test mode with packet generation mode. Offers the possibility to adjust duty of RF Burst at time domain
  - **Cont mode**: Continuous TX out mode. This mode is for TX power test etc. In this mode, TX packet is generated continuously over 95% duty cycle
  - **CW mode**: Only single sinewave tone out mode. This mode is for freq err check
  - **Data Rate**: Choose modulation type to test
  - **Power**: Select or tune the power level. ("0" step is Maximum). The difference between power steps is about 0.8~1 dB/1step
  - **Size**: You can adjust the duty rate with this number. However, the size is not linear as the number, so to set the exact number you need equipment like a spectrum analyzer to check the value. (Equipment setting is set to zero span setting or burst mode setting)

To do TX packet generation:

- To start and stop TX packet generation, use the **Start TX** button and the **Stop TX** button. If you want to make changes for another condition, click **Stop TX** before a new test is started.

Start TX

Stop TX

Figure 11: Start and Stop TX

## DA16200 AT GUI Tool

For example: there is a test setting with 802.11n MCS7, channel 1, 100 bytes packet and power grade 0.

- When the **Start TX** button is clicked, messages as shown in [Figure 12](#) will be shown.

```
AT+RFTX 2412,0,0,100,n65,0,12:34:56:78:90:10,10:20:30:40:50:60,0,long,off,short,off,NO,0,1,0
OK
```

**Figure 12: Debug Console - Start TX**

- When you click the **Stop TX** button, messages as shown in [Figure 13](#) will be shown.


```
AT+RFTX 2412,0,0,100,n65,0,12:34:56:78:90:10,10:20:30:40:50:60,0,long,off,short,off,NO,0,1,0
OK
AT+RFTXSTOP
OK
```

**Figure 13: Debug Console - Stop TX**

### 3.5 RX Test Mode

The settings are made in the **RX Setting** area. See [Figure 14](#).

- **Channel:** Support CH1 ~ CH13
- **Test Time:** Maximum 3600 s (Duration is 1 second fixed)




**Figure 14: Rx Configuration**

- RX Packet Rate
  - $FCS + PHY + Overflow\ packet / Total\ packet = Error\ rate$

## 4 Network Mode


To enable network mode:

1. Open the **Chip Setting** tab.
2. Select the **Network Mode** checkbox. See [Figure 15](#).



**Figure 15: Network Mode Configuration**

- Alternatively, open the **Network Mode** tab and select the **Network Mode** checkbox. See [Figure 16](#).



**Figure 16: Network Mode Tab**

## DA16200 AT GUI Tool

### 4.1 Station Mode

1. In the **Mode Select:** field, select **Station Mode** and click the **Select** button. See [Figure 16](#).
  - The network mode is changed. Next, DA16200 reboots and the station mode setup window opens. See [Figure 17](#).




Figure 17: Setup Window - Station Mode

2. Click the **Scan** button to scan APs. See [Figure 18](#).




Figure 18: Station Mode - SCAN

3. When scanning is finished, choose one AP in the list. See [Figure 19](#).

### DA16200 AT GUI Tool

- 4. Click the **Connect** button.
- 5. If required by the security mode of the AP, fill in a password or key index.




Figure 19: Station Mode - Choose AP and Connect



Figure 20: Debug Console - Connect to AP



## DA16200 AT GUI Tool

### 4.2 AP Mode

1. In the **Mode Select** field, select **AP Mode** and click the **Select** button. See [Figure 16](#).
  - o The network mode changes, DA16200 reboots and the AP Mode setup window opens. See [Figure 21](#).




Figure 21: Setup Window - AP Mode

2. Set the fields SSID, Password, Country, Channel, and Security mode. See [Figure 22](#).

## DA16200 AT GUI Tool

3. Click the **Confirm** button.




Figure 22: AP Configuration

- The Debug Console window messages appears as shown in [Figure 23](#).



Figure 23: Debug Console - AP Configuration

4. In the **DHCP Server** area, make the required settings for the IP addresses and click the **Confirm** button. See [Figure 24](#).

- When a client is connected, the MAC address will be shown as in [Figure 25](#).




Figure 24: DHCP Configuration



Figure 25: Debug Console - DHCP Configuration

DA16200 AT GUI Tool

4.3 Data Transfer (TCP/UDP)

The DA16200 GUI tool provides data transfer functions with TCP/UDP. Before messages are sent with this tool, connect the DA16200 to an access point as shown in [Section 4.1](#). Then click the **Data Transfer** tab. If DA16200 succeeds to connect to an AP, the IP address will be filled in. See [Figure 26](#).




Figure 26: Data Transfer Tab

The DA16200 provides three kinds of sessions: TCP server, TCP client, and UDP session. The user can use these three simultaneously.

4.3.1 TCP Server

To use TCP server, fill in a port number and click the **Connect** button on the **TCP Server** line. When a server is opened, the **X** will change to **O**. See [Figure 27](#).




Figure 27: TCP Server Open

DA16200 AT GUI Tool

The user can connect to the DA16200 TCP server with tools for data exchange like the IO Ninja. When a client connects successfully, its information will be shown as in [Figure 28](#). The DA16200 TCP server can accept up to eight client sessions.




Figure 28: TCP Server Connection with a Client

4.3.2 TCP Client

To connect to a TCP server, fill in the IP address and port number of the server and click the **Connect** button on the **TCP Client** line. When the DA16200 TCP client succeeds to connect, the **X** will change to **O**. See [Figure 29](#).




Figure 29: TCP Client Connection to a Server

DA16200 AT GUI Tool

4.3.3 UDP Session

To open a UDP session, fill in a port number and click the **Start** button. When the DA16200 TCP client succeeds to connect, the **X** will change to **O**. See [Figure 30](#).




Figure 30: UDP Session Open

4.3.4 Data Exchange

To send a message to a peer, first select a session. Each session is slightly different in method.

- **TCP Server:** Select the **TCP Server** checkbox → Select the destination IP in the drop-down list → Type a message → Click the **Send** button (see [Figure 31](#))




Figure 31: TCP Server Data Transfer

DA16200 AT GUI Tool

- **TCP Client:** Select the **TCP Client** checkbox → Type a message → Click the **Send** button (see Figure 32)




Figure 32: TCP Client Data Transfer

- **UDP Session:** Select the **UDP Session** checkbox → Enter the destination IP and port number → Type a message → Click the **Send** button (see Figure 33)




Figure 33: UDP Session Data Transfer

When a session receives a message from a peer, the message is shown in the message window. See Figure 34.



Figure 34: TCP/UDP Data Reception

4.3.5 Data Transfer on DPM Mode

The DA16200 GUI provides TCP/UDP sockets operation in DPM (DA16200 power-save) mode. See Figure 35.




Figure 35: DPM Mode Setting

---

## DA16200 AT GUI Tool

- **DPM Button:** DPM mode Start / End
- **DPM\_STATUS:** DPM state (Disabled / DPM init... / DPM Sleep / DPM wake-up)
- **Sleep Button:** DA16200 returns to DPM sleep state (only available DPM wake-up state)

To initiate TCP/UDP sockets in DPM mode:

1. Open sockets user wants to.
2. Click the **DPM** button to start DPM mode.
3. After all sockets are ready in DPM mode, the **DPM\_STATUS** will change to "DPM sleep".

When DA16200 in DPM sleep state receives a TCP or UDP messages from a peer, it is shown in the message window like in [Figure 34](#).

To send a message in DPM Sleep status:

1. Wake up DA16200 with the switch. The **DPM\_STATUS** will change to "DPM wake-up".
2. Select the session to send, type a message, and click the **Send** button.
3. After sending messages, click the **Sleep** button. The **DPM\_STATUS** will change to "DPM sleep".

To exit DPM mode:

1. Wake up DA16200 with the switch. The **DPM\_STATUS** will change to "DPM Wake-up".
2. Click the **Sleep** button. The **DPM\_STATUS** will change to "Disabled".

DA16200 AT GUI Tool

4.4 MQTT Client

The DA16200 GUI tool provides data transfer functions with MQTT protocol. Before messages are sent with this tool, connect the DA16200 to an access point as shown in Section 4.1. Click the **MQTT Client** tab.

4.4.1 Configuration

Before a connection is made to an MQTT broker, set the required fields for the connection information. See Figure 36.




Figure 36: MQTT Client Tab

- ① Broker IP address
- ② Broker port number
- ③ Subscriber topics (up to 4)
- ④ Publisher topic
- ⑤ Sending PINGREQ cycle (second)
- ⑥ Login ID
- ⑦ Login password
- ⑧ MQTT QoS (0~2)



DA16200 AT GUI Tool

- ⑨ TLS use (0 or 1)
- ⑩ Reset all configuration to default

When the DA16200 MQTT client succeeds to connect, the letter **X** will change to **O**. Moreover, the user can send a PUBLISH message to the broker or receive a message.

4.4.2 Data Exchange

To exchange a message with the broker, connect the MQTT Client.

To send a PUBLISH, type the message and click the **PUBLISH** button. See Figure 37.




Figure 37: MQTT PUBLISH Transfer

When the client receives a message from the broker, the message is displayed in the message window. See Figure 38.




Figure 38: MQTT PUBLISH Reception

4.4.3 MQTT on DPM Mode

The DA16200 GUI provides MQTT client operation in DPM mode. There is the DPM mode setting as shown in Figure 35 in MQTT Client tab.

To initiate MQTT client in DPM mode:

1. After setting up, connect to a MQTT Broker.
2. Click the **DPM** button to start DPM mode.
3. After the MQTT client session is ready in DPM mode, the **DPM\_STATUS** will change to "DPM sleep".

When DA16200 in DPM sleep state receives a PUBLISH from the broker, it is shown in the message window like Figure 38.

## DA16200 AT GUI Tool

To send a message in DPM Sleep status:

1. Wake up DA16200 with the switch. The **DPM\_STATUS** will change to "DPM wake-up".
2. Type a message and click the **PUBLISH** button.
3. After sending messages, click the **Sleep** button. The DPM\_STATUS will change to "DPM sleep".

And to exit DPM mode:

1. Wake up DA16200 with the switch. The **DPM\_STATUS** will change to "DPM Wake-up".
2. Click the **Sleep** button. The **DPM\_STATUS** will change to "Disabled".

### 4.5 TLS Setting

The user can store a TLS certificate that is set with this tool for MQTT, HTTPs, CoAPs, and so on. There are three kinds of items: Root CA, Client Certificate, and Private Key.

DA16200 can only process Privacy Enhanced Mail type(.pem). To enter the certificates directly, input the text and click the **Upload** button with the TLS item selection. If this is done successfully, <Content exists> will appear in the window. See [Figure 39](#).

If the user has TLS certificate files with PEM type, click **File Search** and select the file. The text will be loaded in the window.




Figure 39: TLS Setting Tab

## 5 OTP Mode Setup

To enable OTP mode:

1. Open the **OTP Mode** tab.
2. Click the **OPT Enable** checkbox
  - The current OTP data is as shown in [Figure 40](#).




Figure 40: OTP Mode

**Power calibration** and **temperature calibration** has been completed for the chipset by Dialog and it may not need to be done by the customer.

**Freq Offset cal:** the range of frequency offset calibration is 0x0 ~ 0x7F.

### MAC Address setup

DA16200 has 4 slots to store MAC addresses. The 1st slot is written by Dialog. The user can use 3 slots to write their own MAC address. The MAC address written in the OTP must be an even number. it is used for WLAN0 MAC address (for STA interface), and the next number is automatically used for WLAN1 MAC address (for Soft-AP interface).

To write the MAC address, give a MAC address in the first empty slot and click the **Write** button, then the new address substitutes for the previous address.

## 6 How to Build GUI for DA16200 Board

If necessary, the user can get the source code of the GUI. The GUI source code structure is as shown in [Figure 41](#). Folder **MFCApplication2** contains all the source files (.cpp) and header files(.h) for the GUI. The package total size is about 160 MB. The compile environment used in this document is Visual Studio 2017 professional.

MFCApplication2	
Dialog_GUI.sdf	10,624KB
Dialog_GUI.sln	1KB
MFCApplication2.sdf	77,504KB

Figure 41: GUI Source Codes Structure

Execute the file Dialog\_GUI.sln. The GUI project is loaded as shown in [Figure 42](#).




Figure 42: Dialog GUI Project

DA16200 AT GUI Tool

Click the **Local Windows Debugger** in the menu bar. The GUI is built and executed as shown in Figure 43.




Figure 43: Local Windows Debugger Execution

After the GUI is built, the user can see the newly created Debug folder as shown in Figure 44. Then, the user can execute the GUI modified without compile tools. In general, the GUI file name in the Debug folder is Dialog\_IoTWiFi\_GUI.EXE.

Debug			
MFCApplication2			
Dialog_GUI.sdf	10,624KB	Dialog_IoTWiFi_GUI.EXE	10,425KB
Dialog_GUI.sln	1KB	Dialog_IoTWiFi_GUI.ilc	24,029KB
MFCApplication2.sdf	77,504KB	Dialog_IoTWiFi_GUI.pdb	30,108KB

Figure 44: GUI Files

To modify the source files(.cpp) or header files(.h), the user can open them from the **Solution Explorer** tab as shown in Figure 45.





Figure 45: Solution Explorer Tab

## DA16200 AT GUI Tool

In the **Resource View** tab, the user can manage resources like the GUI windows and the icon as shown in [Figure 46](#).



**Figure 46: Resource View Tab**

## DA16200 AT GUI Tool

## Revision History

Revision	Date	Description
1.4	21-Aug-2020	4.3.5 Data Transfer on DPM Mode Modification 4.4.3 MQTT on DPM Mode Modification Figure 36: MQTT Client Tab Change Figure 45: Solution Explorer Tab
1.3	06-Apr-2020	TCP/UDP, MQTT, and TLS added, GUI Build added
1.2	31-Oct-2019	Finalized for publication
1.1	15-Oct-2019	Editorial review
1.0	03-Jul-2019	Preliminary DRAFT Release

## DA16200 AT GUI Tool

### Status Definitions

Status	Definition
DRAFT	The content of this document is under review and subject to formal approval, which may result in modifications or additions.
APPROVED or unmarked	The content of this document has been approved for publication.

### Disclaimer

Unless otherwise agreed in writing, the Dialog Semiconductor products (and any associated software) referred to in this document are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of a Dialog Semiconductor product (or associated software) can reasonably be expected to result in personal injury, death or severe property or environmental damage. Dialog Semiconductor and its suppliers accept no liability for inclusion and/or use of Dialog Semiconductor products (and any associated software) in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

Information in this document is believed to be accurate and reliable. However, Dialog Semiconductor does not give any representations or warranties, express or implied, as to the accuracy or completeness of such information. Dialog Semiconductor furthermore takes no responsibility whatsoever for the content in this document if provided by any information source outside of Dialog Semiconductor.

Dialog Semiconductor reserves the right to change without notice the information published in this document, including, without limitation, the specification and the design of the related semiconductor products, software and applications. Notwithstanding the foregoing, for any automotive grade version of the device, Dialog Semiconductor reserves the right to change the information published in this document, including, without limitation, the specification and the design of the related semiconductor products, software and applications, in accordance with its standard automotive change notification process.

Applications, software, and semiconductor products described in this document are for illustrative purposes only. Dialog Semiconductor makes no representation or warranty that such applications, software and semiconductor products will be suitable for the specified use without further testing or modification. Unless otherwise agreed in writing, such testing or modification is the sole responsibility of the customer and Dialog Semiconductor excludes all liability in this respect.

Nothing in this document may be construed as a license for customer to use the Dialog Semiconductor products, software and applications referred to in this document. Such license must be separately sought by customer with Dialog Semiconductor.

All use of Dialog Semiconductor products, software and applications referred to in this document is subject to Dialog Semiconductor's [Standard Terms and Conditions of Sale](http://www.dialog-semiconductor.com), available on the company website ([www.dialog-semiconductor.com](http://www.dialog-semiconductor.com)) unless otherwise stated.

Dialog, Dialog Semiconductor and the Dialog logo are trademarks of Dialog Semiconductor Plc or its subsidiaries. All other product or service names and marks are the property of their respective owners.

© 2020 Dialog Semiconductor. All rights reserved

## Contacting Dialog Semiconductor

**United Kingdom (Headquarters)**  
Dialog Semiconductor (UK) LTD  
Phone: +44 1793 757700

**Germany**  
Dialog Semiconductor GmbH  
Phone: +49 7021 805-0

**The Netherlands**  
Dialog Semiconductor B.V.  
Phone: +31 73 640 8822

**Email:**  
[enquiry@diasemi.com](mailto:enquiry@diasemi.com)

**North America**  
Dialog Semiconductor Inc.  
Phone: +1 408 845 8500

**Japan**  
Dialog Semiconductor K. K.  
Phone: +81 3 5769 5100

**Taiwan**  
Dialog Semiconductor Taiwan  
Phone: +886 281 786 222

**Web site:**  
[www.dialog-semiconductor.com](http://www.dialog-semiconductor.com)

**Hong Kong**  
Dialog Semiconductor Hong Kong  
Phone: +852 2607 4271

**Korea**  
Dialog Semiconductor Korea  
Phone: +82 2 3469 8200

**China (Shenzhen)**  
Dialog Semiconductor China  
Phone: +86 755 2981 3669

**China (Shanghai)**  
Dialog Semiconductor China  
Phone: +86 21 5424 9058