

User Manual

DA16200 AT GUI Tool

UM-WI-004

DA16200 AT GUI Tool

Contents

Contents 2

Figures..... 3

Terms and Definitions..... 4

References 4

1 Introduction..... 5

 1.1 Certification Mode 5

 1.2 Network Mode 5

 1.3 OTP Mode 6

2 How to Connect 6

 2.1 USB to Serial Driver 6

3 DA16200 SDK or Firmware Selection 6

4 How to Run GUI with DA16200 EVK 7

 4.1 Connection and Running..... 7

 4.2 COM Port and Baud Rate Configuration..... 9

 4.3 RF Certification Mode 10

 4.4 TX Test Mode..... 11

 4.5 RX Test Mode 13

5 Network Mode..... 14

 5.1 Station Mode 15

 5.2 AP Mode 17

 5.3 Data Transfer (TCP/UDP) 19

 5.3.1 TCP Server 19

 5.3.2 TCP Client 20

 5.3.3 UDP Session 21

 5.3.4 Data Exchange 21

 5.3.5 Data Transfer on DPM Mode..... 22

 5.4 MQTT Client..... 24

 5.4.1 Configuration 24

 5.4.2 Data Exchange 25

 5.4.3 MQTT on DPM Mode..... 25

 5.5 TLS Setting 26

6 OTP Mode Setup..... 27

Revision History 28

DA16200 AT GUI Tool

Figures

Figure 1: DA16200 EVK GUI 5

Figure 2: Development Kit Connections 7

Figure 3: AT GUI 8

Figure 4: RS232 Setup - Disconnected 9

Figure 5: RS232 Setup - Connected 9

Figure 6: Debug Console - Connected 9

Figure 7: Certification Mode Configuration 10

Figure 8: Tx Test Mode Configuration 11

Figure 9: Debug Console - TX Mode 11

Figure 10: Start and Stop TX 12

Figure 11: Debug Console - Start TX 12

Figure 12: Debug Console - Stop TX 12

Figure 13: Rx Configuration 13

Figure 14: Network Mode Configuration 14

Figure 15: Setup Window - Station Mode 15

Figure 16: Station Mode - SCAN 15

Figure 17: Station Mode - Choose AP and Connect 16

Figure 18: Debug Console - Connect to AP 16

Figure 19: Setup Window - AP Mode 17

Figure 20: AP Configuration 18

Figure 21: Debug Console - AP Configuration 18

Figure 22: DHCP Configuration 18

Figure 23: Debug Console - DHCP Configuration 19

Figure 24: Data Transfer Tab 19

Figure 25: TCP Server Open 19

Figure 26: TCP Server Connection with a Client 20

Figure 27: TCP Client Connection to a Server 20

Figure 28: UDP Session Open 21

Figure 29: TCP Server Data Transfer 21

Figure 30: TCP Client Data Transfer 22

Figure 31: UDP Session Data Transfer 22

Figure 32: TCP/UDP Data Reception 22

Figure 33: DPM Mode Setting 22

Figure 34: MQTT Client Tab 24

Figure 35: MQTT PUBLISH Transfer 25

Figure 36: MQTT PUBLISH Reception 25

Figure 37: TLS Setting Tab 26

Figure 38: OTP Mode 27

DA16200 AT GUI Tool**Terms and Definitions**

AP	Access Point
AT	AT Command Interpreter Software Subsystem, or Attention
CoAP	Constrained Application Protocol
DHCP	Dynamic Host Configuration Protocol
EVK	Evaluation Kit
GUI	Graphical User Interface
HTTP	Hyper Text Transfer Protocol
MFC	Microsoft Foundation Class
MQTT	Message Queuing Telemetry Transport
OTP	One Time Programmable
PC	Personal Computer
QFN	Quad Flat No-lead
SDK	Software Development Kit
SSID	Service Set Identifier
STA	STAtion
TCP	Transmission Control Protocol
TLS	Transport Layer Security
UART	Universal Asynchronous Receiver Transmitter
UDP	User Datagram Protocol
USB	Universal Serial Bus

References

- [1] DA16200, Datasheet, Dialog Semiconductor
- [2] DA16200, SDK Programmer Guide, User Manual, Dialog Semiconductor
- [3] DA16200, EVK User Guide, Dialog Semiconductor
- [4] DA16200, AT Command User Guide, Dialog Semiconductor

DA16200 AT GUI Tool

1 Introduction

The DA16200 GUI tool lets users control the DA16200 EVK in a GUI environment. There are three modes of operation: Certification mode, Network mode and OTP mode (see [Figure 1](#)).




Figure 1: DA16200 EVK GUI

1.1 Certification Mode

This mode is for Wi-Fi RF test (Tx power, Rx sensitivity, etc.) also known as “TEST Mode”.

1.2 Network Mode

With Network mode, the Station or AP mode of the DA16200 is tested.

- **AP mode:** Soft-AP test with configurable parameters like SSID, security, DHCP Server, etc.
- **Station mode:** STA test to search and connect to an Access Point and check/test the STA function

After the network mode is set, the user can test the TCP/UDP or the MQTT and manage the TLS certificates.

- **Data Transfer:** message exchange through the TCP Server/Client, and UDP session
- **MQTT Client:** message exchange through the MQTT protocol
- **TLS Setting:** management of TLS certificate that is set (e.g. Root CA, Client Certificate, Client Private Key)

DA16200 AT GUI Tool

1.3 OTP Mode

This mode is for **power calibration** and **temperature calibration with OTP memory location**.

2 How to Connect

2.1 USB to Serial Driver

The DA16200 evaluation board supports USB to serial interface. The user connects to DA16200 EVK with the PC through a micro-USB cable and then two COM ports will be detected automatically.

One (UART0) is for console command and the other (UART1) is for AT command. Normally, the higher number COM port is for AT commands and the lower number COM port is for the console.

- Required the FT232 Driver installation for Windows
 - In most cases, it will be installed automatically

The FTDI driver for the FT2232 FTDI chip used on DA16200 EVK is available for download at the following link: http://www.ftdichip.com/Drivers/CDM/CDM21224_Setup.zip

- See the EVK User Guide [3] to find information about the UART1 port. AT GUI tool uses UART1 port.
- To update with a new DA16200 firmware, see the DA16200 EVK User Guide [3].

3 DA16200 SDK or Firmware Selection

There are a number of types of SDK and firmware for DA16200 such as Generic and Manufacture that can be found in DA16200 SDK/Image packages. Consider the kinds of tests you plan to determine which SDK or firmware should be picked up.

- Certification or OTP Mode:
 - SDK: DA16200_SDK_Manufacture_QFN_xxx.zip
 - Firmware: DA16200_IMG_Manufacture_QFN
- Network Mode:
 - SDK: DA16200_SDK_Generic_QFN xxx.zip
 - The `__SUPPORT_ATCMD__` where can be found in `config_generic_sdk.h` file should be enabled.

```
[\src\customer\config_generic_sdk.h]

// AT-CMD features
#define    __SUPPORT_ATCMD__                // Support AT-CMD
```

- Firmware: ATCMD firmware should be picked such as DA16200_IMG_Generic_QFN_ATCMD, DA16200_IMG_Generic_FcCSP_LP_ATCMD or DA16200_IMG_Generic_FcCSP_NP_ATCMD depending on SoC package type.

DA16200 AT GUI Tool

4 How to Run GUI with DA16200 EVK

4.1 Connection and Running

DA16200 AT GUI program is a single executable file.

NOTE

If there is an error with the message "a DLL file (e.g. *vcruntime140.dll* or *mfc1400u.dll*) is missing", then install Microsoft Visual Studio redistributable package (<https://www.microsoft.com/en-us/download/details.aspx?id=48145>) or copy the .dll file into the Windows system folder (C:\Windows\System32 or C:\Windows\SysWOW64).

The program setup sequence is:

1. Connect the DA16200 Development Kit to the host PC as shown in
- 2.
3. [Figure 2](#).




Figure 2: Development Kit Connections

NOTE

See the EVK User Guide [\[3\]](#) to know which port to use.

DA16200 AT GUI Tool

- 4. Start the AT GUI program.




Figure 3: AT GUI

DA16200 AT GUI Tool

4.2 COM Port and Baud Rate Configuration

- When the AT GUI program runs, the connection status is red (not connected). If the program does not detect any COM port, click the **Refresh** button to refresh the COM Port. See [Figure 4](#).




Figure 4: RS232 Setup - Disconnected

- Select a COM port and click the **OPEN** button and wait for a few seconds. See [Figure 5](#) and [Figure 6](#).
 - The connection status will soon change to a green color and the Connection Status field shows "Connected" in a green color. This means that communication is OK.




Figure 5: RS232 Setup - Connected

- In the Debug Console window (in the black box), the message "Echo on" is shown.




Figure 6: Debug Console - Connected

DA16200 AT GUI Tool

4.3 RF Certification Mode

To enable certification mode:

- 1. Open the **Settings** tab. See [Figure 7](#).
- 2. In the **RF Mode** area, select the **Certification Mode** check box.




Figure 7: Certification Mode Configuration

DA16200 AT GUI Tool

4.4 TX Test Mode

1. Open the **Certification Mode** tab. See [Figure 8](#).




Figure 8: Tx Test Mode Configuration

2. Click the **Mode Select** button ([Figure 8](#)). A confirmation message is shown as in [Figure 9](#). This is a normal state.





Figure 9: Debug Console - TX Mode

3. Select the **Data Rate**, **Channel**, and **Power** for the purpose of the test.
 - **Packet mode**: this is the normal test mode with packet generation mode. Offers the possibility to adjust duty of RF Burst at time domain
 - **Cont mode**: Continuous TX out mode. This mode is for TX power test etc. In this mode, TX packet is generated continuously over 95% duty cycle
 - **CW mode**: Only single sinewave tone out mode. This mode is for freq err check
 - **Data Rate**: Choose modulation type to test
 - **Power**: Select or tune the power level. ("0" step is Maximum). The difference between power steps is about 0.8~1 dB/1step
 - **Size**: You can adjust the duty rate with this number. However, the size is not linear as the number, so to set the exact number you need equipment like a spectrum analyzer to check the value. (Equipment setting is set to zero span setting or burst mode setting)

DA16200 AT GUI Tool

To do TX packet generation:

- To start and stop TX packet generation, use the **Start TX** button and the **Stop TX** button. If you want to make changes for another condition, click **Stop TX** before a new test is started.



Start TX

Stop TX

Figure 10: Start and Stop TX

For example: there is a test setting with 802.11n MCS7, channel 1, 100 bytes packet and power grade 0.

- When the **Start TX** button is clicked, messages as shown in Figure 11 will be shown.

```
AT+RFTX 2412,0,0,100,n65,0,12:34:56:78:90:10,10:20:30:40:50:60,0,long,off,short,off,NO,0,1,0
OK
```

Figure 11: Debug Console - Start TX

- When you click the **Stop TX** button, messages as shown in Figure 12 will be shown.

```
AT+RFTX 2412,0,0,100,n65,0,12:34:56:78:90:10,10:20:30:40:50:60,0,long,off,short,off,NO,0,1,0
OK
AT+RFTXSTOP
OK
```


Figure 12: Debug Console - Stop TX

DA16200 AT GUI Tool

4.5 RX Test Mode

The settings are made in the **RX Setting** area. See [Figure 13](#).

- **Channel:** Support CH1 ~ CH13
- **Test Time:** Maximum 3600 s (Duration is 1 second fixed)



RX Setting		
Channel :	CH1 (2412MHz) ▾	Start RX
Test Time :	0 ▾	Seconds
(0 for infinite) Clear Stat		
Time :	/ s	
Vaild		Packets
FCS Error		Packets
PHY Error		Packets
Overflow Error		Packets
Total Packet		Packets
Error Rate		%

Figure 13: Rx Configuration

- RX Packet Rate
 - $FCS + PHY + Overflow\ packet / Total\ packet = Error\ rate$

DA16200 AT GUI Tool

5 Network Mode

To enable network mode:

1. Open the **Settings** tab.
2. Select the **Network Mode** checkbox. See [Figure 14](#).




Figure 14: Network Mode Configuration

DA16200 AT GUI Tool

5.1 Station Mode

1. In the **Mode Select:** field, select **Station Mode**. See [Error! Reference source not found.](#)
 - o The network mode is changed. Next, DA16200 reboots and the station mode setup window opens. See [Figure 15](#).




Figure 15: Setup Window - Station Mode

2. Click the **Scan** button to scan APs. See [Figure 16](#).




Figure 16: Station Mode - SCAN

DA16200 AT GUI Tool

3. When scanning is finished, choose one AP in the list. See [Figure 17](#).
4. Click the **Connect** button.
5. If required by the security mode of the AP, fill in a password or key index.




Figure 17: Station Mode - Choose AP and Connect



Figure 18: Debug Console - Connect to AP

DA16200 AT GUI Tool

5.2 AP Mode

1. In the **Mode Select** field, select **AP Mode**. See [Error! Reference source not found.](#)
 - The network mode changes, DA16200 reboots and the AP Mode setup window opens. See [Figure 19](#).




Figure 19: Setup Window - AP Mode

2. Set the fields SSID, Password, Country, Channel, and Security mode. See [Figure 20](#).

DA16200 AT GUI Tool

3. Click the **Confirm** button.

The AP Configuration dialog box contains the following fields and controls:

- SSID :
- Password :
- Country : Channel :
- Security :
-

Figure 20: AP Configuration

- The Debug Console window messages appears as shown in [Figure 21](#).

The Debug Console window displays the following text:

```
AT+WFSAP=DA16200_AP1,3,1,N123456789,11,KR
+WFSAP:DA16200_AP1
OK
AT+RESTART
OK
ATE
+INIT:DONE,1
ATE
Echo on
OK
```

At the bottom of the window, there are and buttons.

Figure 21: Debug Console - AP Configuration

4. In the **DHCP Server** area, make the required settings for the IP addresses and click the **Confirm** button. See [Figure 22](#).
- When a client is connected, the MAC address will be shown as in [Figure 23](#).

The DHCP Server configuration dialog box contains the following fields and controls:

- Start IP :
- End IP :
- DNS IP :
- Enable Disable
-

Figure 22: DHCP Configuration

DA16200 AT GUI Tool

```

AT+NWDHR=10,0,0,2,10,0,0,10
OK
AT+NWDHDNS=8,8,8,8
OK
AT+NWDHS=1
OK
+WFCST:34:f3:9a:0a:d4:3f
    
```

Figure 23: Debug Console - DHCP Configuration

5.3 Data Transfer (TCP/UDP)

The DA16200 GUI tool provides data transfer functions with TCP/UDP. Before messages are sent with this tool, connect the DA16200 to an access point as shown in [Section 5.1](#). Then click the **Data Transfer** tab. If DA16200 succeeds to connect to an AP, the IP address will be filled in. See [Figure 24](#).




Figure 24: Data Transfer Tab

The DA16200 provides three kinds of sessions: TCP server, TCP client, and UDP session. The user can use these three simultaneously.

5.3.1 TCP Server

To use TCP server, fill in a port number and click the **Connect** button on the **TCP Server** line. When a server is opened, the **X** will change to **O**. See [Figure 25](#).




Figure 25: TCP Server Open

DA16200 AT GUI Tool

The user can connect to the DA16200 TCP server with tools for data exchange like the IO Ninja. When a client connects successfully, its information will be shown as in Figure 26. The DA16200 TCP server can accept up to eight client sessions.




Figure 26: TCP Server Connection with a Client

5.3.2 TCP Client

To connect to a TCP server, fill in the IP address and port number of the server and click the **Connect** button on the **TCP Client** line. When the DA16200 TCP client succeeds to connect, the **X** will change to **O**. See Figure 27.




Figure 27: TCP Client Connection to a Server

DA16200 AT GUI Tool

5.3.3 UDP Session

To open a UDP session, fill in a port number and click the **Start** button. When the DA16200 TCP client succeeds to connect, the **X** will change to **O**. See [Figure 28](#). TODO:




Figure 28: UDP Session Open

5.3.4 Data Exchange

To send a message to a peer, first select a session. Each session is slightly different in method.

- **TCP Server:** Select the **TCP Server** checkbox → Select the destination IP in the drop-down list → Type a message → Click the **Send** button (see [Figure 29](#))




Figure 29: TCP Server Data Transfer

DA16200 AT GUI Tool

- **TCP Client:** Select the **TCP Client** checkbox → Type a message → Click the **Send** button (see Figure 30)




Figure 30: TCP Client Data Transfer

- **UDP Session:** Select the **UDP Session** checkbox → Enter the destination IP and port number → Type a message → Click the **Send** button (see Figure 31)




Figure 31: UDP Session Data Transfer

When a session receives a message from a peer, the message is shown in the message window. See Figure 32.




Figure 32: TCP/UDP Data Reception

5.3.5 Data Transfer on DPM Mode

The DA16200 GUI provides TCP/UDP sockets operation in DPM (DA16200 power-save) mode. See Figure 33.




Figure 33: DPM Mode Setting

- **DPM Button:** DPM mode Start / End
- **DPM_STATUS:** DPM state (Disabled / DPM init... / DPM Sleep / DPM wake-up)
- **Sleep Button:** DA16200 returns to DPM sleep state (only available DPM wake-up state)

To initiate TCP/UDP sockets in DPM mode:

1. Open sockets user wants to.
2. Click the **DPM** button to start DPM mode.

DA16200 AT GUI Tool

3. After all sockets are ready in DPM mode, the **DPM_STATUS** will change to "DPM sleep".

When DA16200 in DPM sleep state receives a TCP or UDP messages from a peer, it is shown in the message window like in [Figure 32](#).

To send a message in DPM Sleep status:

1. Wake up DA16200 with the switch. The **DPM_STATUS** will change to "DPM wake-up".
2. Select the session to send, type a message, and click the **Send** button.
3. After sending messages, click the **Sleep** button. The **DPM_STATUS** will change to "DPM sleep".

To exit DPM mode:

1. Wake up DA16200 with the switch. The **DPM_STATUS** will change to "DPM Wake-up".
2. Click the **Sleep** button. The **DPM_STATUS** will change to "Disabled".

DA16200 AT GUI Tool

5.4 MQTT Client

The DA16200 GUI tool provides data transfer functions with MQTT protocol. Before messages are sent with this tool, connect the DA16200 to an access point as shown in Section 5.1. Click the **MQTT Client** tab.

5.4.1 Configuration

Before a connection is made to an MQTT broker, set the required fields for the connection information. See Figure 34.




Figure 34: MQTT Client Tab

- ① Broker IP address
- ② Broker port number
- ③ Subscriber topics (up to 4)
- ④ Publisher topic
- ⑤ Sending PINGREQ cycle (second)
- ⑥ Login ID

DA16200 AT GUI Tool

- ⑦ Login password
- ⑧ MQTT QoS (0~2)
- ⑨ TLS use (0 or 1)
- ⑩ Reset all configuration to default

When the DA16200 MQTT client succeeds to connect, the letter **X** will change to **O**. Moreover, the user can send a PUBLISH message to the broker or receive a message.

5.4.2 Data Exchange

To exchange a message with the broker, connect the MQTT Client.

To send a PUBLISH, type the message and click the **PUBLISH** button. See [Figure 35](#).




Figure 35: MQTT PUBLISH Transfer

When the client receives a message from the broker, the message is displayed in the message window. See [Figure 36](#).




Figure 36: MQTT PUBLISH Reception

5.4.3 MQTT on DPM Mode

The DA16200 GUI provides MQTT client operation in DPM mode. There is the DPM mode setting as shown in [Figure 33](#) in MQTT Client tab.

To initiate MQTT client in DPM mode:

1. After setting up, connect to a MQTT Broker.
2. Click the **DPM** button to start DPM mode.
3. After the MQTT client session is ready in DPM mode, the **DPM_STATUS** will change to "DPM sleep".

When DA16200 in DPM sleep state receives a PUBLISH from the broker, it is shown in the message window like [Figure 36](#).

DA16200 AT GUI Tool

To send a message in DPM Sleep status:

1. Wake up DA16200 with the switch. The **DPM_STATUS** will change to "DPM wake-up".
2. Type a message and click the **PUBLISH** button.
3. After sending messages, click the **Sleep** button. The DPM_STATUS will change to "DPM sleep".

And to exit DPM mode:

1. Wake up DA16200 with the switch. The **DPM_STATUS** will change to "DPM Wake-up".
2. Click the **Sleep** button. The **DPM_STATUS** will change to "Disabled".

5.5 TLS Setting

The user can store a TLS certificate that is set with this tool for MQTT, HTTPs, CoAPs, and so on. There are three kinds of items: Root CA, Client Certificate, and Private Key.

DA16200 can only process Privacy Enhanced Mail type(.pem). To enter the certificates directly, input the text and click the **Upload** button with the TLS item selection. If this is done successfully, <Content exists> will appear in the window. See [Figure 37](#).

If the user has TLS certificate files with PEM type, click **File Search** and select the file. The text will be loaded in the window.




Figure 37: TLS Setting Tab

DA16200 AT GUI Tool

6 OTP Mode Setup

To enable OTP mode:

1. Open the **OTP Mode** tab.
2. Click the **OPT Enable** checkbox
 - The current OTP data is as shown in [Figure 38](#).




Figure 38: OTP Mode

Power calibration and **temperature calibration** has been completed for the chipset by Dialog and it may not need to be done by the customer.

Freq Offset cal: the range of frequency offset calibration is 0x0 ~ 0x7F.

MAC Address setup

DA16200 has 4 slots to store MAC addresses. The 1st slot is written by Dialog. The user can use 3 slots to write their own MAC address. The MAC address written in the OTP must be an even number. it is used for WLAN0 MAC address (for STA interface), and the next number is automatically used for WLAN1 MAC address (for Soft-AP interface).

To write the MAC address, give a MAC address in the first empty slot and click the **Write** button, then the new address substitutes for the previous address.

DA16200 AT GUI Tool

Revision History

Revision	Date	Description
1.5	06-Jan-2021	Revised as the user interface changes of the tool.
1.4	21-Aug-2020	4.3.5 Data Transfer on DPM Mode Modification 4.4.3 MQTT on DPM Mode Modification Figure 36: MQTT Client Tab Change Figure 45: Solution Explorer Tab
1.3	06-Apr-2020	TCP/UDP, MQTT, and TLS added, GUI Build added
1.2	31-Oct-2019	Finalized for publication
1.1	15-Oct-2019	Editorial review
1.0	03-Jul-2019	Preliminary DRAFT Release

DA16200 AT GUI Tool

Status Definitions

Status	Definition
DRAFT	The content of this document is under review and subject to formal approval, which may result in modifications or additions.
APPROVED or unmarked	The content of this document has been approved for publication.

Disclaimer

Unless otherwise agreed in writing, the Dialog Semiconductor products (and any associated software) referred to in this document are not designed, authorized or warranted to be suitable for use in life support, life-critical or safety-critical systems or equipment, nor in applications where failure or malfunction of a Dialog Semiconductor product (or associated software) can reasonably be expected to result in personal injury, death or severe property or environmental damage. Dialog Semiconductor and its suppliers accept no liability for inclusion and/or use of Dialog Semiconductor products (and any associated software) in such equipment or applications and therefore such inclusion and/or use is at the customer's own risk.

Information in this document is believed to be accurate and reliable. However, Dialog Semiconductor does not give any representations or warranties, express or implied, as to the accuracy or completeness of such information. Dialog Semiconductor furthermore takes no responsibility whatsoever for the content in this document if provided by any information source outside of Dialog Semiconductor.

Dialog Semiconductor reserves the right to change without notice the information published in this document, including, without limitation, the specification and the design of the related semiconductor products, software and applications. Notwithstanding the foregoing, for any automotive grade version of the device, Dialog Semiconductor reserves the right to change the information published in this document, including, without limitation, the specification and the design of the related semiconductor products, software and applications, in accordance with its standard automotive change notification process.

Applications, software, and semiconductor products described in this document are for illustrative purposes only. Dialog Semiconductor makes no representation or warranty that such applications, software and semiconductor products will be suitable for the specified use without further testing or modification. Unless otherwise agreed in writing, such testing or modification is the sole responsibility of the customer and Dialog Semiconductor excludes all liability in this respect.

Nothing in this document may be construed as a license for customer to use the Dialog Semiconductor products, software and applications referred to in this document. Such license must be separately sought by customer with Dialog Semiconductor.

All use of Dialog Semiconductor products, software and applications referred to in this document is subject to Dialog Semiconductor's [Standard Terms and Conditions of Sale](http://www.dialog-semiconductor.com), available on the company website (www.dialog-semiconductor.com) unless otherwise stated.

Dialog, Dialog Semiconductor and the Dialog logo are trademarks of Dialog Semiconductor Plc or its subsidiaries. All other product or service names and marks are the property of their respective owners.

© 2021 Dialog Semiconductor. All rights reserved

Contacting Dialog Semiconductor

United Kingdom (Headquarters)
Dialog Semiconductor (UK) LTD
Phone: +44 1793 757700

Germany
Dialog Semiconductor GmbH
Phone: +49 7021 805-0

The Netherlands
Dialog Semiconductor B.V.
Phone: +31 73 640 8822

Email:
enquiry@diasemi.com

North America
Dialog Semiconductor Inc.
Phone: +1 408 845 8500

Japan
Dialog Semiconductor K. K.
Phone: +81 3 5769 5100

Taiwan
Dialog Semiconductor Taiwan
Phone: +886 281 786 222

Web site:
www.dialog-semiconductor.com

Hong Kong
Dialog Semiconductor Hong Kong
Phone: +852 2607 4271

Korea
Dialog Semiconductor Korea
Phone: +82 2 3469 8200

China (Shenzhen)
Dialog Semiconductor China
Phone: +86 755 2981 3669

China (Shanghai)
Dialog Semiconductor China
Phone: +86 21 5424 9058