

Application Note

DA9063L Schematic Checklist

AN-PM-107

Abstract

Optimizing the schematic for DA9063L ensures correct and efficient operation of the PMIC and the system. This is achieved by selecting appropriate external passive components, and appropriate configuration of the PMIC OTP.

DA9063L Schematic Checklist

Contents

Abstract 1

Contents 2

1 Terms and Definitions..... 3

2 References 3

3 Introduction..... 4

4 Schematic Checklist 4

5 Further Assistance..... 8

Revision History 9

DA9063L Schematic Checklist

1 Terms and Definitions

PMIC	Power Management Integrated Circuit
DA906x	DA9061, DA9062, DA9063, DA9063L
GUI	Graphical User Interface
OTP	One-Time Programmable (memory)
RTC	Real-Time Clock
SoC	System on (a) Chip
PMIC	Power Management Integrated Circuit
GPIO	General Purpose Input / Output

2 References

- [1] DA9063L, Datasheet, Dialog Semiconductor

DA9063L Schematic Checklist

3 Introduction

DA9063L is a high-current system PMIC suitable for dual- and quad-core processors used in smartphones, tablets, ultra-books, and other handheld and automotive applications that require up to 12 A core processor supply.

This checklist is intended to help a hardware designer identify common errors that can arise in schematics containing the DA9063L. The checklist is only a reference to common errors, and is not a substitute for rigorous system development and an understanding of the PMIC behavior as described in the DA9063L datasheet [1].

4 Schematic Checklist

Table 1: Checklist

General		Comments	
Design name			
Schematic version			
Review date			
OTP variant	Notes	Checked (Y/N)	Comments
Which OTP variant is being used?	This can provide useful background for the review.		
OTP version number			
Core Operation			
V _{sys}	2.8 V to 5.5 V		
V _{DDIO}	1.2 V to 3.6 V		
VSYS capacitor	1 μ F		
IREF resistor	200 k Ω . Must be \leq 1 % tolerance.		
VREF capacitor	220 nF		
VLNREF	220 nF		
VBBAT capacitor	No connect.		
VDDCORE capacitor	2.2 μ F		
V _{CP}	47 nF		
Crystal	The RTC requires an external crystal of 32.768 kHz and load capacitors.		
XTAL_IN and XTAL_OUT	If a crystal or an external 32 kHz source is not required, then both pins should be grounded.		

DA9063L Schematic Checklist

Core operation	Notes	Checked (Y/N)	Comments
nRESET timing	The nRESET timer control can be set in the GUI. RESET_EVENT sets the timer start reference and RESET_TIMER sets the delay until nRESET is released. Make sure nRESET is active until all important rails have turned on.		
nRESET pin	Register control IRQ_TYPE determines if the pin is push-pull or open-drain. Check that an external pull-up is present if open-drain.		
nONKEY	nONKEY should be either pulled high to V _{SYS} or tied to V _{SYS} , and never left floating.		
nOFF	nOFF should be either pulled high to V _{SYS} or tied to V _{SYS} , and never left floating.		
nSHUTDOWN	nSHUTDOWN should be either pulled high to V _{SYS} or tied to V _{SYS} , and never left floating.		
CHG_WAKE	Wake-up signal from companion charger which triggers a start-up and is a temporary supply voltage for the PMIC (VBUS_PROT in case of an inserted supply until the charger buck provides power to V _{SYS}) Should not be left floating. Pull down to ground, via 10 k Ω .		
TP	TP should not be left floating. Pull down to ground, via 10 k Ω . Ideally, a test-point will be provided for system debug.		
LDOs			
LDO input voltages	2.8 V to 5.5 V If supplied by a buck, the minimum voltage is 1.5 V.		
LDO input capacitor	Note 1		
LDO output capacitor	2.2 μ F		
LDO output voltage	LDO3: 0.9 V to 3.44 V LDO7/8/11: 0.9 V to 3.6 V LDO9: 0.95 V to 3.6 V		
LDO output current	LDO3/7/8/9: 200 mA LDO11: 300 mA		
DVC_<x> register control	If VDLO<x>_SEL_A and VDLO<x>_SEL_B have different voltages and only one specific voltage is desired, then the regulator needs to be set correctly.		

DA9063L Schematic Checklist

Bucks	Notes	Checked (Y/N)	Comments
Buck supply voltage	2.8 V to 5.5 V		
Input capacitors	Note 2 , Note 3		
Buck output current	BUCKCORE1 and BUCKCORE2 : 2500 A BUCKPRO : 2500 mA BUCKPERI : 1500 mA BUCKMEM : 1500 mA BUCKIO : 1500 mA		
Buck: current limit register settings I_{LIM}	Controlled with B<x>_ILIM register. BUCKCORE1 and BUCKCORE2 : <ul style="list-style-type: none"> Full Current Mode: 1000 mA to 4000 mA Half Current Mode: 500 mA to 2000 mA BUCKPRO : 500 mA to 2000 mA BUCKPERI : 1500 mA to 3000 mA BUCKMEM : 1500 mA to 3000 mA BUCKIO : 1500 mA to 3000 mA		
Minimum ISAT values required at current limits	Current limit:	ISAT:	
	3400 mA	3800 mA	
	2800 mA	3100 mA	
	2100 mA	2400 mA	
	1700 mA	1700 mA	
CORE1 / CORE2 dual-phase mode	5 A output. Enabled by controls BCORE_MERGE. Outputs from both inductors need to be routed together.		
MEM / IO dual-phase mode	3 A output. Enabled by controls BUCK_MERGE. Buck outputs should share the same inductor.		
DVC_<x> register control	If VBUCK<x>_SEL_A and VBUCL<x>_SEL_B have different voltages and only one specific voltage is desired, then the regulator needs to be set correctly.		

DA9063L Schematic Checklist

Bucks	Notes	Checked (Y/N)	Comments
Output capacitors	BUCKCORE1 / BUCKCORE2: Full Current Mode: 2 x 47 μ F Half Current Mode: 2 x 22 μ F BUCKPRO: Full Current Mode: 2 x 47 μ F Half Current Mode: 2 x 22 μ F BUCKPERI: 2 x 22 μ F BUCKMEM: Full Current Mode: 2 x 47 μ F Half Current Mode: 2 x 22 μ F BUCKIO: 2 x 22 μ F		
GPIOs			
Unused GPIOs	Check that they are one of the following: <ul style="list-style-type: none"> • configured as an input, with internal pull-down enabled via registers CONFIG_L and CONFIG_K, or, • configured as an output, or, • tied to GND 		
GPIO events	Check unused GPIOs have events masked in register IRQ_MASK_C.		
Are there any GPIOs configured to have special features? (SYS_EN, PWR_EN, Watchdog trigger input)	Check the signal behavior. Ensure the port is correctly configured as active-high or active-low using control GPIO<x>_TYPE.		

DA9063L Schematic Checklist

Power Sequencer	Notes	Checked (Y/N)	Comments
Start-up sequence	Is it correct for the system requirements?		
WAIT_STEP and dummy slots	Has the WAIT_STEP feature been used correctly, or set to 0x00? If dummy (empty) slots are used, are they correct?		
Minimize in-rush	Turning all regulators on in the same slot will cause a large inrush current and potentially cause a drop-in input voltage and cause the PMIC to power down.		
Are the sequencer pointers placed in a suitable slot?	PART_DOWN ≤ SYSTEM_END SYSTEM_END ≤ POWER_END POWER_END ≤ MAX_COUNT		

Note 1 2 x 1 μF shared by all VDD_LDOx pins if they are all close together, for example, all attached to a power/split plane.

Note 2 22 μF within 1.5 mm of each BUCKCORE1, BUCKCORE2 and BUCKPRO supply pin.

Note 3 10μF within 1.5 mm of each BUCKPERI, BUCKIO and BUCKMEM supply pin or 1 x 22μF if all are attached to a PCB power/split plane

5 Further Assistance

For further assistance on debugging and for a detailed schematic and OTP check, please refer to the DA9063L Datasheet found on the Dialog website (<https://www.dialog-semiconductor.com/pmics>) or contact your local FAE.

Revision History

Revision	Date	Description
1.0	16-Nov-2017	Initial version.

DA9063L Schematic Checklist

Status Definitions

Status	Definition
DRAFT	The content of this document is under review and subject to formal approval, which may result in modifications or additions.
APPROVED or unmarked	The content of this document has been approved for publication.

Disclaimer

Information in this document is believed to be accurate and reliable. However, Dialog Semiconductor does not give any representations or warranties, expressed or implied, as to the accuracy or completeness of such information. Dialog Semiconductor furthermore takes no responsibility whatsoever for the content in this document if provided by any information source outside of Dialog Semiconductor.

Dialog Semiconductor reserves the right to change without notice the information published in this document, including without limitation the specification and the design of the related semiconductor products, software and applications.

Applications, software, and semiconductor products described in this document are for illustrative purposes only. Dialog Semiconductor makes no representation or warranty that such applications, software and semiconductor products will be suitable for the specified use without further testing or modification. Unless otherwise agreed in writing, such testing or modification is the sole responsibility of the customer and Dialog Semiconductor excludes all liability in this respect.

Customer notes that nothing in this document may be construed as a license for customer to use the Dialog Semiconductor products, software and applications referred to in this document. Such license must be separately sought by customer with Dialog Semiconductor.

All use of Dialog Semiconductor products, software and applications referred to in this document are subject to Dialog Semiconductor's [Standard Terms and Conditions of Sale](#), available on the company website (www.dialog-semiconductor.com) unless otherwise stated.

Dialog and the Dialog logo are trademarks of Dialog Semiconductor plc or its subsidiaries. All other product or service names are the property of their respective owners.

© 2019 Dialog Semiconductor. All rights reserved.

Contacting Dialog Semiconductor

United Kingdom (Headquarters)

Dialog Semiconductor (UK) LTD
Phone: +44 1793 757700

Germany

Dialog Semiconductor GmbH
Phone: +49 7021 805-0

The Netherlands

Dialog Semiconductor B.V.
Phone: +31 73 640 8822

Email:

enquiry@diasemi.com

North America

Dialog Semiconductor Inc.
Phone: +1 408 845 8500

Japan

Dialog Semiconductor K. K.
Phone: +81 3 5769 5100

Taiwan

Dialog Semiconductor Taiwan
Phone: +886 281 786 222

Web site:

www.dialog-semiconductor.com

Hong Kong

Dialog Semiconductor Hong Kong
Phone: +852 2607 4271

Korea

Dialog Semiconductor Korea
Phone: +82 2 3469 8200

China (Shenzhen)

Dialog Semiconductor China
Phone: +86 755 2981 3669

China (Shanghai)

Dialog Semiconductor China
Phone: +86 21 5424 9058